

**Rustins**

**Knotting**  
**BSS 1336**



**For sealing knots**

# Rustins

## Knotting - BSS 1336

**IMPORTANT** - Do not use under dyes, stains, water based varnish and water based paints. If a water based coating is to be used, first seal the knotting with an oil based primer or undercoat, this will prevent the knotting discolouring the coating. Knotting prevents the discolouration of paint and is not designed to hold back excess resin in knots. Any excess resin should be removed using a heat gun prior to decorating.

For sealing knots, resinous and creosoted timber to prevent bleeding through paint film. Sandpaper surface smooth before applying knotting liberally over knots and surrounding area. Do not sandpaper knotting once applied. Resinous and creosoted timber should be sealed completely with 2 coats. Allow 1 hour before priming. Clean brushes with methylated spirits.



Danger

**Highly flammable liquid and vapour.**

**Take precautionary measures against static discharge.**

**IF ON SKIN (or hair):** Remove immediately all contaminated clothing. Rinse skin with water.

**Wear eye protection.**

**In case of fire:** Use carbon dioxide for extinction.

**Store in a well-ventilated place. Keep cool.**

**Dispose of contents/container to hazardous or special waste collection point.**

Please refer to Product Data Sheet for full information at [www.rustins.co.uk](http://www.rustins.co.uk)



EU limit value for this product (Cat A/b): 750g/l (2010).  
This product contains max. 700g/l VOC



**300ml e**

For information on Rustins' products visit our website at [www.rustins.co.uk](http://www.rustins.co.uk) or contact us at Rustins Ltd, Waterloo Road, London, NW2 7TX United Kingdom [rustins@rustins.co.uk](mailto:rustins@rustins.co.uk) Telephone: +44 (0)20 8450 4666