



Wudfil

Wood Repair Filler



Instructions

1. Make sure area to be filled is clean and free from grease, resin etc.
2. Using the spatula provided take amount of paste required from tin. Add a small amount of hardener from the tube. (Approx. a pea size of hardener to a golf ball size of paste.)
3. Mix thoroughly together and use immediately. Sand when hard. Usually after about ten minutes. This time will vary with ambient temperature.
4. Staining. For best results always sand surface of cured filler, before staining and finishing.



Size: **Bench Pack**

'Wudfil Easy Stain'

All the traditional virtues of the 'Original' Filler, but can (after sanding) be stained with most stains. Indeed sanding and shaping has never been easier, tools remain sharp and sanding belts last longer. If you are a professional, products from 'Wudcare' have been designed for you,

Warning contains styrene

H226 Flammable Liquid & Vapour. H319 Causes serious eye irritation.
H332 Harmful if inhaled. H315 Causes skin irritation.
P208 Wear protective gloves & wear eye & face protection.
P102 Keep out the reach of children.
P101 Show this label in case of medical emergency.
P210 Keep away from heat/flames/hot surfaces. No smoking.
P304 If inhaled remove victim to fresh air.
P501 Dispose waste & tins safely.

mail: info@wudcare.co.uk
www.wudcare.co.uk