



KITCHEN SURFACE CLEANER

DEGREASER & LIMESCALE REMOVER

CLEANS, RESTORES & PROTECTS



SHAKE TO ACTIVATE!

KITCHEN SURFACE CLEANER


Our intelligent range of cleaners have been specially formulated to be kind to surfaces and target specific cleaning tasks. House Mate™ Kitchen Surface Cleaner is a unique formula that combines a degreaser for removing grease and spills with a limescale remover to remove water stains. House Mate™ makes light work of your housework.

Just shake it to wake it!

DIRECTIONS FOR USE: 1. SHAKE WELL BEFORE USE. 2. Turn the spray to ON. 3. Spray onto surface, after a few minutes rinse well. For a polished finish, wipe the surface with a clean, dry cloth. **Do not use:** On marble or other natural stone materials or on old or worn enamel. Before using on painted surfaces, test on a small inconspicuous area first. The product should be stored in its original, intact packaging in a dry, cool place, protected from sunlight and frost.

Ingredients: Less than 5% anionic surfactants.
Further Ingredients: Perfumes (Limonene, Citral, Linalool).
Contains: (R)-p-mentha-1,8-diene; d-limonene. May produce an allergic reaction. Keep out of reach of children. If medical advice is needed, have product container or label at hand. Avoid breathing spray.

UFI: VA9G-R05T-300J-SVX9
House Mate is a registered trade mark of Rustins Ltd, 51 Waterloo Road, London NW2 7TX, UK.
Tel: +44 (0)20 8450 4666
ROI: Excellence Ltd, 43 Grange Parade, Dublin D13 Y860, Ireland.
Tel: +353 1 - 832 3300
www.house-mate.info



HM20121-R 500 ml